


The roman ogee may be the most popular edge treatment in woodworking, and it is certainly one of the most beautiful and varied in classic design.



are recommended. ORDER NO. ORDER NO. ORDER NO. ORDER NO. ORDER NO. S**=**Ø**6**mm S**=Ø6,35**mm S=Ø8mm S=Ø**12**mm S=Ø12,7mm 10 740.270.11 840.270.11 940.270.11 940.770.11 840.770.11 10 740.350.11 840.350.11 940.350.11 940.850.11 840.850.11

941.285.11

941.380.11

941.785.11

941.880.11

SHOP TIPS: for best results, multiple passes

841.285.11

841.380.11

990.423.00 791.003.00 990.058.00 991.057.00 990.423.00 791.003.00 990.058.00 991.057.00 841.785.11 990.423.00 791.003.00 990.058.00 991.057.00 841.880.11 990.423.00 791.003.00 990.058.00 991.057.00

Classical Ogee Bits

D

28,7

38,1

33,4

42,8

11,5

17,3

18,5

13

10

10

741.285.11


741.380.11

4

4

6,4

6,4



R		D mm	I mm	8	ORDER NO. S=Ø6mm	ORDER NO. S=Ø 6,35 mm	ORDER NO. S=Ø8mm	ORDER NO. S=Ø12mm	ORDER NO. S=Ø 12,7 mm	Spare parts			
4	.	28,7	13	10	744.287.11	844.287.11	944.287.11	944.787.11	844.787.11	990.423.00	791.003.00	990.058.00	991.057.00
6,4-	4,8	35	18,5	10	744.350.11	844.350.11	944.350.11	944.850.11	844.850.11	990.423.00	791.003.00	990.058.00	991.057.00
4		28,7	13	10	745.287.11	845.287.11	945.287.11	945.787.11	845.787.11	990.422.00	791.002.00	990.058.00	991.057.00
6,4-	4,8	35	18,5	10	745.350.11	845.350.11	945.350.11	945.850.11	845.850.11	990.422.00	791.002.00	990.058.00	991.057.00
,			, ,										

SHOP TIPS: after resharpening, replace bearing as follow:
791.002.00 (Ø9,5mm) with undersized bearing **791.062.00** (Ø9,3mm)
791.003.00 (Ø12,7mm) with undersized bearing **791.063.00** (Ø12,5mm)

Snara narte